



- | Part | Part Description                 | Part Number    |
|------|----------------------------------|----------------|
| 1    | EFI Unit                         | TS0HSH120/240Y |
| 2    | Fuse Housing                     | HEB-AA         |
| 3    | Fuse                             | ATDR30         |
| 4    | 12 AWG Wire (8" section)         | 2              |
| 5    | Heat Shrink (2" section 2" diam) | 4              |

### Assembly Instructions:

- 1 Strip only DNE end of each section of black wire (4), removing about  $\frac{3}{8}$ " of insulation. Insert in "load" side of fuseholder(2).
- 2 Strip ends of both black wires on EFI unit, and insert in non-load end of fuseholder (2B).
- 3 Crimp all 4 fuseholder ends to respective wires. Insert Fuse into fuse housing, and hand-tighten 2A onto 2B.
- 4 Cover crimps with heat 2" heat shrink, and apply 170F+ with a heat gun. 2 layers of heat shrink are required, and must be "shrunk" sequentially.

